

## INSTRUCTIONS FOR USING THE J TRANS SINGLE, 4in1 ELEMENT MUG PRESSES

### How to set up your mug press:

1. Connect power lead and turn on black power switch on right hand side of control unit.
2. Press MODE button once. Use left and right arrow buttons to set initial low temperature at 110C/ 230°F (You can toggle the display between °C and °F by pressing the °C/°F button on the control panel.)
3. Press MODE button once. Use left and right arrow buttons to set higher transfer temperature at 165°C/330°F.
4. Press MODE button once. Use left and right arrow buttons to set transfer time at 100.
5. Press MODE button once. Your press is now ready to use.

### How to use your mug press:

1. Turn on black power switch on right hand side of control unit.
2. When initial temperature has been reached (your mug press will repeatedly beep), place a mug with transfer in the element/sleeve, pull the handle forward to close the press then press the **green** start/stop button on the front of the control unit.
3. The temperature will rise to the higher temperature, at which point the timer will automatically count down from 100.
4. When the heat transfer is complete (ie. counter reaches zero), the press will make a continuous beep.
5. Press the **green** start/stop button, push the handle back, and carefully remove the mug.
6. The press will drop in temperature to the lower initial temperature, and the press is now ready to print the next mug.

**NOTE:** Please always leave the handle back (open) when the press is on but not being used. The pressure of the element sleeve can be adjusted by turning the thumb knob next to the element sleeve to ensure consistent firm pressure all around the transfer area.

**\*\*Please ensure the mug press is turned off and cool before changing the heat element.\*\***

