

INFORMATION & INSTRUCTIONS

Please read Instructions carefully and feel free to contact Merlin Transfers with any questions before use.
Tel: 01702 600200 email: sales@merlintransfers.com

- Back Print** 'Laser Light 140 Transfer Paper' (in red lettering)
- Recommended Fabrics** White or light coloured fabrics including 100% cotton, 100% polyester or poly/cotton blends, Mouse Mats, Polyester Knits, Polyester Mesh, Satin.
- Equipment Required** Computer, Colour laser Printer / Copier, Heat Press
- Printing**
- ◆ Design your image and resize if necessary **NB:** Ensure your design is in mirror image
 - ◆ CL 140 should be printed using the by-pass tray in your printer
(If your printer has a rear exit door that will allow the paper to exit straight out the back we suggest you test the paper using this configuration.)
 - ◆ Print on the white matt coated side of the transfer sheet
 - ◆ Set your printer paper setting from **UltraHeavy/Thick to Label***
(depending on the settings in your printer driver)
- *NB:** These settings are guides only, you will need to conduct your own tests
All technical information and recommendations are based on tests we have conducted.
Users should conduct their own tests before proceeding.
- Pressing**
- ◆ Prepress Fabric for 5 – 10 seconds
 - ◆ Trim Transfer as required then place image side down onto the fabric
 - ◆ Press at 190-195°C for 25 – 30 seconds using maximum pressure
 - ◆ Peel backing off warm (wait 3 – 4 seconds)
NB: If you are having difficulties peeling the backing paper off the shirt, while the fabric is still hot, gently tug on the side of the shirt, the backing will lift off.
- Washing Instructions**
- ◆ Wait 24 hours before washing, and turn textile inside out.
 - ◆ Machine wash in warm water using a mild detergent (40°C)
 - ◆ **Recommended:** HANG DRY
 - ◆ Tumble dry with cool or warm air setting. Do not use fabric softeners.
 - ◆ After washing we recommend turning shirt inside out and ironing the image from the back.
NB: Do not Dry Clean.
- Storage** This paper has an indefinite shelf life when stored at room temperature. Keep away from direct heat, sunlight and humidity

Any enquiries relating to our products and their usage are always welcome
If you find yourself unsure of how to use this product please feel free to contact us on:
Tel: 01702 600200 Email: sales@merlintransfers.com